

FWUwx.. + FWUyz.. + FWU00F1

FWU height first enclosure (w)	H1 (mm)	FWU height second enclosure (y)	H2 (mm)	FWU height second enclosure (y)	H2 (mm)	FWU height second enclosure (y)	H2 (mm)	FWU height second enclosure (y)	H2 (mm)	FWU height second enclosure (y)	H2 (mm)	FWU height second enclosure (y)	H2 (mm)
3	502	3	1055	4	1205	5	1355	6	1505	7	1655	8	1805
4	652	3	1205	4	1355	5	1505	6	1655	7	1805		
5	802	3	1355	4	1505	5	1655	6	1805				
6	952	3	1505	4	1655	5	1805						
7	1102	3	1655	4	1805								
8	1252	3	1805										

FWU width first enclosure (x)	L1 (mm)	FWU width second enclosure (z)	L2 (mm)	FWU width second enclosure (z)	L2 (mm)	FWU width second enclosure (z)	L2 (mm)
1	560	1	1165	2	1415	3	1665
2	810	1	1415	2	1665	3	1915
3	1060	1	1665	2	1915	3	2165

